

INSULATED BOX LINERS



The **Next Step** in Temperature Controlled Packaging



Keep Cool




Stay Fresh



125 Sherwood Ave | Farmingdale, NY 11735
1-888-COLDPAK | www.nortechlabs.com

Available In:



Drum Liners • Pouches • Pallet Covers • Box Liners • Cargo Kits • Sheet Liners LD2-LD3 Kits • Air Cargo Covers • Roll Stock • And More....

Environmentally FDA Friendly:

- Cool Blue™ is the new **green!** Our Cool Blue™ insulation is made with recycled FDA approved plastic and reusable foil. 

Cool Blue™ Tec:

- Unlike traditional foam Cool Blue™ insulation acts like a shield against the three types of heat transfer, conduction, convection and radiant. The bubbles and poly prevent conduction and convection heat transfer while the foil reflects 97% of the radiant heat.

Performance:

- Tests have shown that Cool Blue™ insulation retains the desired temperature for several days. However, we recommend letting us send you a free sample to test yourself.

Cool Blue™ Savings

- Cool Blue™ Insulation costs less than your traditional foam insulation. We pass this savings on to you!

Shipping Savings

- Cool Blue™ insulation takes up less space than traditional foam. With this space savings you can put more of your product in the box or choose to save money on shipping with a lighter box weight. Either way you increase your profits with Cool Blue™ insulation.


Storage Savings

- Foam containers take up more space than our Cool Blue™ which folds, bends, and stores easily saving you valuable warehouse space.

Proof in the Pudding:


- Let us send you a free Cool Blue™ insulation box insert to try yourself. Call for more information and a free sample today!

Bubble laminated to a unique blue film for durability and protective cushioning.



High quality foil provides greater insulation and control of temperature ranges.

Testing:




Testing was performed in a controlled environment using FedEx overnight boxes lined with each individual material and gel packs.

We recommend and welcome the opportunity to do your own testing and comparison with Cool Blue™ insulation against your current packaging.

Call now or e-mail us to request your FREE sample today!

Products:

Pallet Covers



- Ideal for LTL or truckload shipments
- Cost effective
- Custom built to fit any size pallet dimensions

Product Size	Units Per Case
48" x 42" x 24" Pallet Covers	12
48" x 42" x 36" Pallet Covers	8
48" x 42" x 40" Pallet Covers	2
48" x 42" x 48" Pallet Covers	5
48" x 42" x 60" Pallet Covers	2
48" x 42" x 72" Pallet Covers	5



Roll Goods

- Available in multiple sizes
- Great for lining 48' or 53' trailer gaylords, and more

Product Size	Units Per Case
48" x 125' Roll	1
48" 250' Roll	1
48" x 500' Roll	1
60" x 125' Roll	1
60" x 250' Roll	1
62" x 125' Roll	1
62" x 250" Roll	1
72" x 125' Roll	1
72" x 250' Roll	1

Products:

Cargo Kit & Drum Liners



- Kits are pre-measured and cut specifically to fit LD2 through LD11, P6 and P9A, D container, E, EH, and EO

Product Size	Units Per Case
56" x 39" x 39" (D Container)	2
40" x 28" x 24" (E Container)	5
35" x 21" x 21" (EH Container)	8
29" x 16" x 16" (EO Container)	12

Mailers

- Ideal for overnight boxes
- Available in 11 standard sizes
- Custom sizes to fit your specific needs available



Product Size	Units Per Case
11" x 15" Insulated Mailers	130
12" x 17" Insulated Mailers	100
15" x 17" Insulated Mailers	100
15" x 23" Insulated Mailers	70
18" x 22" Insulated Mailers	60
23" x 18" Insulated Mailers	60
4" x 5" Insulated Mailers	500
6" x 6.5" Insulated Mailers	70
6.5" x 10.5" Insulated Mailers	70
7" x 15" Insulated Mailers	200
8" x 11" Insulated Mailers	200

Products:

Patented Insulated Box Liners (Box Inserts)



- Cool Blue™ box inserts cost generally 10%-20% less than styrofoam EPS coolers
- Box inserts fold down for easy storage, taking up less warehouse space and **reduce your inbound freight charges**
- Heat reflecting technology out performs foam, takes up a fraction of space, and costs less
- Bubble based products add to cushioning for protection of the contents
- Dirt smudges show easily on foam, while Cool Blue™'s shiny exterior provides a clean and pleasant presentation
- Custom sizes available, call for pricing today!

Product Size	Units Per Case
10" x 10" x 10" Box Inserts	30
11.25" x 11.25" x 8.5" Box Inserts	25
12" x 10" x 9" Box Inserts	30
12" x 12" x 12" Box Inserts	25
14" x 14" x 14" Box Inserts	20
16" x 12" x 8" Box Inserts	25
16" x 12.5" x 12.5" Box Inserts	15
16" x 16" x 16" Box Inserts	15
18" x 12" x 12" Box Inserts	20
18" x 12" x 6" Box Inserts	20
18" x 18" x 16" Box Inserts	15
18" x 18" x 18" Box Inserts	12
22" x 14" x 12" Box Inserts	15
22" x 14" x 6" Box Inserts	20
23" x 23" x 20" Box Inserts	10
24" x 18" x 18" Box Inserts	10
6" x 6" x 6" Box Inserts	100
8" x 6" x 9" Box Inserts	50
8" x 8" x 8" Box Inserts	50

Follow These 7 Easy Steps!



MSDS Spec Sheet

 This product is made of FDA approved recycled materials

Foil

Physical Properties

Value

Aluminum Foil	0.0003 inch
Mullen Burst	14 psi
Low Temperature Resistance	Remains Flexible no delamination at -40°F
High Temperature Resistance	Remains Flexible no delamination at 240°F
Water Immersion	No Delamination

FDA Approved Low Density Polyethylene

Mechanical Properties

Value

Tensile Strength @ Yield, psi	1,450
Recycled Resins	30% up to 100%